

# Instructions

## Lense interchange:

First make sure, that you have the left lens for the left part of the frame and the right lens for the right part of the frame.

### OUT:

Hold the frame at the bottom and gently apply pressure to the lens from the bottom-backside until it pops out.

Please polish the lenses with your YEYKEY microfiber bag

YEYKEY®

### IN:

Slide the topside of the lens from the front into the frame. Then gently apply pressure to the bottom of the lens until it pops back in.

